

UCOM

WORKLED 160



USER GUIDE

CE



V.1.1 - 01/09

GB/IE/CY The features described in this manual are published with reservation to modifications.

1	Intended Purpose	4
2	Safety advice	4
2.1	General	4
2.2	Electric shock	4
3	Package content	5
4	Description	5
5	Installation	5
6	Using the Workled 160	5
7	Technical specifications	6
8	Cleaning	6
9	Maintenance	6
10	Disposal of the device (environment)	6
11	Service address and hot-line support	6
12	Declaration of conformity and manufacturer	6
13	Warranty	7
13.1	Warranty period	7
13.2	Warranty handling	7
13.3	Warranty exclusions	7
	Declaration of conformity	11

1 Intended Purpose

This product is intended to be used as work light in the work shed, attic, basement, garage for painting or home decorating etc.

The device is only for private use and is not intended for any commercial purposes.

2 Safety advice

2.1 General

- Always read the safety instructions carefully and keep this user guide for future reference.
- Pass this user guide together with the device to other users.
- Do not expose the device to extreme hot or cold temperatures or to direct sunlight. The device may also not be installed next to heat sources.
- Protect the device from dirt and dust.
- Do not use the device in bath, shower or other damp room. The device is not full waterproof.
- Do not leave the device unattended when plugged in. Unplug the device immediately from the main power after use.
- Make sure that the device is not too close to heat sources.

2.2 Electric shock

- Do not operate the device if the mains plug, cable or the equipment itself is damaged.
- Follow the basic safety precautions for all electronic equipment when using this product.
- Do not use the device if it is not working properly, dropped or damaged.
- Repairs to electrical appliances must only be carried out by qualified persons. Incorrect repairs can lead to considerable danger for the user. In the event of repairs, please contact our customer service.
- Don't disassemble this device. It doesn't contain parts that can be repaired by the user.
- Dangerous voltages are present inside the device. Never open the housing.
- If a fault develops during use or before you start to clean the equipment, unplug the power cable from the socket.
- Children frequently underestimate the dangers associated with electrical equipment. Therefore you must never leave children unsupervised in the vicinity of electrical equipment. The product is not a toy. Don't let children play with it.
- Equipment connected to the mains during a thunderstorm can be damaged by lightning. Therefore you should pull the plug out of the mains socket during a storm.
- To completely disconnect the device from the electricity supply, the plug must be removed from the socket. Pull on the plug itself and never on the cable.
- Protect the mains cable from hot surfaces or other sources of damage and do not allow it to become constrained.
- Unwind the mains cable completely before use. Make sure that the mains cable does not represent a trip hazard.


3 Package content

Check the completeness of the box and the device before use.

- 1 x Workled - model Workled 160
- 1 x User guide
- 1 x Service card

4 Description

1. Carry handle
2. Reflector; 160 LED's
3. Stand
4. Adjustable bracket
5. Butterfly screw
6. Nut
7. Nut holder
8. Mains power connector



5 Installation

- Rotate the butterfly screw **5** counter clockwise and remove it from the lamp stand **3**.
- Pull the nut holder **7** from the lamp stand. Make sure the nut **6** does not fall out of the nut holder **7**.
- Slide the adjustable bracket **4**, which is already attached to the lamp, over the lamp stand **3**.
- Put the nut holder **7** back into position.
- Rotate the nut holder **7** and align it with the screw hole.
- Screw the butterfly screw **5** into the nut.
- Direct the lamp to the desired position and fix the butterfly screw **5**.

6 Using the Workled 160

- Plug the end of the power cord into the 230V wall outlet to activate the LED light.
- With the multi-position stand, you can focus the light exactly where it is needed.



The wall outlet must be close and accessible to switch the light off when danger occurs.

7 Technical specifications

- Model: Workled 160
- 160 white LED's
- LED intensity: maximum 12.000 mcd/LED
- Life time of LED: rated up to 100.000 hours
- Input voltage: 230V, 50Hz
- Rated power: maximum 15W
- Protection type: IP44 (splash waterproof)

8 Cleaning

To clean the device, wipe with a soft cloth dampened with water. To clean dirty joints, use a non-scratching brush.



Don't use a cleaner, solvents or similar liquids on the unit. They can damage the case and leak inside, causing permanent damage.

9 Maintenance

Check regularly the connectors and cables on malfunctions and let defect parts repaired by a professional.

10 Disposal of the device (environment)



At the end of the product life cycle, you should not throw this product into the normal household garbage but bring the product to a collection point for the recycling of electrical and electronic equipment. The symbol on the product, user guide and/or box indicate this.

Some of the product materials can be re-used if you bring them to a recycling point. By re-using some parts or raw materials from used products you make an important contribution to the protection of the environment. Please contact your local authorities in case you need more information on the collection points in your area.

11 Service address and hot-line support

The service addresses are printed on the extra service card included in the package or can be found on www.ucom.be

12 Declaration of conformity and manufacturer

Topcom Europe Nv.
Grauwmeer 17
3001 Heverlee
Belgium

The declaration of conformity can be found on the last page of this user guide

13 Warranty

13.1 Warranty period

The devices have a 36-month warranty period. The warranty period starts on the day the new unit is purchased.

Consumables or defects causing a negligible effect on operation or value of the equipment are not covered.

The warranty has to be proven by presentation of the original or copy of the purchase receipt, on which the date of purchase and the unit-model are indicated.

13.2 Warranty handling

A faulty unit needs to be returned to an authorized service centre including a valid purchase note.

If the unit develops a fault during the warranty period, the service centre will repair any defects caused by material or manufacturing faults free of charge, by either repairing or exchanging the faulty units or parts of the faulty units. In case of replacement, colour and model can be different from the original purchased unit.

The initial purchase date shall determine the start of the warranty period. The warranty period is not extended if the unit is exchanged or repaired by the service centre.

13.3 Warranty exclusions

Damage or defects caused by incorrect treatment or operation and damage resulting from use of non-original parts or accessories are not covered by the warranty.

The warranty does not cover damage caused by outside factors, such as lightning, water and fire, nor any damage caused during transportation.

No warranty can be claimed if the serial number on the units has been changed, removed or rendered illegible.

Any warranty claims will be invalid if the unit has been repaired, altered or modified by the buyer.

DECLARATION OF CONFORMITY

We as manufacturer, Topcom Europe Nv, Grauwmeer 17 , 3001 Heverlee , Belgium, declare that our product :

Product name: Workled 160

is in compliance with the essential requirements and other relevant provisions of the directive 2004/108/EG and 2006/95/EG and carries the CE mark accordingly.

Supplementary information:

The product complies with the requirements of:

- EN 60598-1:2004
- EN 60598-2-4 :1997
- EN55015 :2006
- EN61000-3-2 :2006
- EN61000-3-3 :1995 +A1 :2001 +A2 :2005
- EN61547 : 1995 + A1 : 2000

Date: 10/10/2008.
Place: Heverlee , Belgium
Name: Verheyden Geert
Function: Technical Director

Signature:



European contact: Topcom Europe Nv, R&D department, Research Park, Grauwmeer 17, 3001 Heverlee, Belgium. Tel : +32 16 398920 , Fax : +32 16 398939

UCOM

WORKLED 160

visit our website

www.ucom.be

MD2500268